



Nivel eléctrico 9" fw-544406000

www.twilight.mx








Model No: 54-440-600

Please read through this owners manual carefully before using your new tool. Use your tool properly and only for its intended use.



Fowler's 9" Laser Level provides instant 4 x 90° digital inclination display. With embedded magnets on its measuring surface, a beam splitter projects a 90° laser cross hair for leveling at a distance. It also includes a 1/4-20 mount for tripod use.



Operating Instructions:

- C Level: Push "O" button to turn the level on, Level will appear on the upper left corner and the tool is ready to take level measurements.
- Tilt %: Push "Tilt %" button, % will appear in the upper right corner to measure tangent tilt rate %; 100% = 45°. To return back to level measurements, push "Tilt %" button again.
- Hold: Push "Hold" button, Hold will appear in the upper center to hold the measured reading; to return to normal measuring, push the "Hold" button once again.
- Bevel: Push the "Bevel" button to set relative Zero on any surface. To switch back to level measuring, push "O Level " button for 3 seconds.
- Laser: Push "Laser" button to use the laser for measuring; to turn off the laser, push the "Laser" button once again.

Specifications

Measuring Range:

4 x 90°

Resolution:

 0.05°

Accuracy:

+0.1°

Battery:

Standard 9 volt

Battery Life:

Approximately 1 year

WARNING

- NEVER look directly into the laser beam. Improper use may cause injury to the eyes.
- DO NOT direct the laser beam on another person. Even a laser of minor capacity may cause iniury to the eyes.
- This digital laser/level is not a toy and must be stored out of children's reach.



- LASER RADIATION
- DO NOT STARE INTO BEAM
- CLASS 2 LASER PRODUCT



+52(81) 8115-1400 / +52 (81) 8173-4300

LADA Sin Costo: 01 800 087 43 75

E-mail: ventas@twilight.mx

www.twilight.mx



